



• Réf. : BL18064



• Réf. : BL18067

## LAVABO HYPER ASEPTIQUE PVC HYPER ASEPTIC BASIN PVC

• Lavabo / auge chirurgical hyper aseptique moulé d'une seule pièce sans raccord ou collage. Sans débordement, avec dossier de protection mural, formes arrondies et pente interne. Sans trop plein. Il est muni de moyen de fixation en acier inoxydable. Matériaux en résine polyester armée, renforcée sur les zones de stress avec revêtement gelcoat blanc Iso NPG de qualité sanitaire. Les tuyaux d'alimentation sont en HDPE résistants à la chloration.

### 3 MODÈLES:

- **Lavabo électronique** : Le déclenchement de l'arrivée d'eau se fait automatiquement par détection de présence. Ce système est muni de purge automatique (6h/12h/Off). Réglage simplifié en façade via télécommande. Boîtier EV facile à d'éclipser pour maintenance.
- **Lavabo à genoux** : Le déclenchement de l'arrivée d'eau se fait par commande mécanique fémorale (genoux).
- **Lavabo à coude** : Le déclenchement de l'arrivée d'eau se fait par commande mécanique à coude.

• *Aseptic surgical basin one-piece molded washing station without any fittings or gluing. Without overflow, with wall protection backsplash, rounded shapes and internal slope. This basin is equipped with stainless steel fastening means. Materials made of reinforced polyester resin, reinforced on stress zones with white gelcoat coating Iso NPG of sanitary quality. The supply hoses are made of HDPE resistant to chlorination.*

### 3 MODELS:

- **Electronic wash basin**: The water supply is triggered by automated presence detection. This system is equipped with automatic drain (6h / 12h / Off). Simplified front panel adjustment via remote control. EV box easy to unclip for maintenance.
- **Knees wash basin**: The water supply will be triggered by mechanical femoral control (kneeling).
- **Elbow wash basin**: The water supply will be triggered by mechanical elbow control.

	Réf.	Long./Length	Larg./Width	Haut./Height	Poids/Weights
Lavabo électronique 3 postes / Electronic washbasin 3 positions	BL18060	200 cm	57 cm	74,5 cm	27 kg
Lavabo à genoux 3 postes / Wash basin on knees 3 positions	BL18061	200 cm	57 cm	74,5 cm	27 kg
Lavabo à coude 3 postes / Elbow wash basin 3 positions	BL18062	200 cm	57 cm	74,5 cm	27 kg
Lavabo électronique 2 postes / Electronic wash basin 2 positions	BL18063	150 cm	57 cm	74,5 cm	19 kg
Lavabo à genoux 2 postes / Wash basin on knees 2 positions	BL18064	150 cm	57 cm	74,5 cm	19 kg
Lavabo à coude 2 postes / Elbow wash basin 2 positions	BL18065	150 cm	57 cm	74,5 cm	19 kg
Lavabo électronique 1 poste / Electronic wash basin 1 position	BL18066	90 cm	57 cm	78,5 cm	15 kg
Lavabo à genoux 1 poste / Wash basin on knees 1 position	BL18067	90 cm	57 cm	78,5 cm	15 kg
Lavabo à coude 1 poste / Elbow wash basin 1 position	BL18068	90 cm	57 cm	78,5 cm	15 kg